

# COMMANDassurance<sup>TM</sup>

## Instructions:


Driver Performance  
report  
6/15/2022



**Command  
Alkon**


# Driver Performance

COMMANDassurance provides critical data to save time and costs, reduce liability, and identify poor driver performance. This report measures how well the drivers follow established processes to ensure that critical slump values are obtained.




## Accessing the Driver Performance Report

1. Visit the [CONNEX](#) site and enter your credentials.




2. In CONNEX, select the **Insights** option under the *Analysis* menu.




3. On the Insights page, select the **Analysis** menu.



4. Locate the **COMMANDassurance - Driver Performance** option.



## Filters



Filters:

- **Date Range**
- **Plant(s)**
  - If set to view by plant, select a plant to see the summary for only that individual plant.
- **Driver(s)**
  - Select a driver to see scores for only that individual driver.

The **Filter** (🔍) icon displays categories that contribute to calculating the drivers' scores. Users can identify which categories should be included or excluded when scoring drivers by setting the appropriate drop-downs to either **Yes** or **No**.



Client: [Dropdown] Driver: [Dropdown] [Filter Icon] [Refresh Icon]

**Driver Score Setup**

- Include Batched Slump: [Yes]
- Include Not Over Mixed: [Yes]
- Include Water Mixed (30 Turns): [Yes]
- Include Enroute Turns Under 3 Rpm: [Yes]
- Include Safe Rpm at High Speed: [Yes]
- Include Job Site Slump: [Yes]
- Include Under 300 Turns: [Yes]
- Include Arrived in Spec: [Yes]
- Ticket Data Quality: [Valid]



Excluded categories are still displayed in the categorized score charts, but are not included when calculating the driver's score.


## Summary Tab

The Summary is split into four sections:


- Overall Averages (Summary)

Summary				
<b>49.7%</b>	<b>14</b>	<b>14</b>	<b>70</b>	<b>1.5</b>
Avg Score	Avg. Loaded (mins)	Avg. Washing (mins)	Avg. Controllable (mins)	Avg. Over Mixed Minutes


- Driver Scores



- Scores Over Time



- Driver Scores by Category




The provided data can be broken down by driver or by plant using the **Summarize By** drop-down.

---

## Details Tab

---

The Detail tab provides a breakdown of the driver's scoring on a per-ticket basis.




Driver Full Name	Ticket	Date	Avg Score	Excessive Errands Turns	Insufficient Mirrors	Over 300 Turns	Has Initial Slump	Unexplained Slump Change	Unsafe Driving	Overstated	Has At Job Slump	Arrived in Spec
BC160476	Feb 01, 21	38%										
BC160521	Feb 02, 21	50%										
BC160529	Feb 02, 21	63%										
BC160541	Feb 03, 21	63%										
BC160553	Feb 03, 21	75%										
BC160577	Feb 03, 21	50%										
BC160607	Feb 04, 21	50%										
BC160646	Feb 04, 21	50%										
BC160670	Feb 04, 21	50%										
BC160702	Feb 04, 21	50%										
BC160725	Feb 05, 21	38%										
BC160738	Feb 05, 21	50%										
BC160749	Feb 05, 21	63%										
BC160762	Feb 05, 21	63%										
BC160783	Feb 05, 21	63%										
BC160797	Feb 06, 21	50%										
BC160819	Feb 06, 21	63%										
BC160830	Feb 08, 21	63%										
BC160853	Feb 08, 21	63%										
BC160874	Feb 08, 21	75%										
BC160888	Feb 08, 21	50%										
BC160948	Feb 09, 21	63%										
BC160976	Feb 09, 21	50%										
BC161001	Feb 09, 21	50%										
BC161069	Feb 10, 21	38%										
BC161087	Feb 10, 21	50%										
BC161121	Feb 10, 21	38%										
BC161145	Feb 10, 21	38%										

- Each ticket is highlighted either green (pass) or red (fail) for each category.


## Exports

### PDF Export:


1. Click the PDF icon in the top right of the report



2. In the popup window, click the **This View** drop-down and select **Specific sheets from this dashboard**




### 3. Select the "Export Scores" tile



4. Click **Download** to generate the PDF file.
5. NOTE: The **Summary By** drop-down will determine if the export data is grouped by Plant or by Driver.

## Excel Export:

1. Select the **Details** Tab
2. Click the Excel icon in the upper right



3. In the popup, be sure **Export Breakdown** is selected
4. Choose either Excel or CSV and click Download.

